

LEFT SPEAKER			VHS #1	SPEAKER AMP	time code gen/rdr	time code d/a	RIGHT SPEAKER
VT 2		A=2W-15 B=2T-21	VT 4	VT 10	VT 6	A=2W-16 B=2T-22	VT 8
		2r-1 2r-2 2r-3				2r-10 2r-11 2r-12	
VT 1			VT 3	VT 9	VT 5		VT 7
wohler	wohler	2r-4 2r-5 2r-6	wohler wohler	wohler wohler	wohler wohler	2r-13 2r-14 2r-15	wohler wohler
		2r-7 2r-8 2r-9			QC SCOPE		
2R-19	2R-27		2R-21	2T-3	QC MON	2R-23	2T-5
					ROUTER 15		
2R-20	2R-28	2T-1	2R-22	2T-4	LANCE		
						2R-24	2T-6
						2T-7	2T-8
						2R-26	2T-10
ROUTER 1	ROUTER 2	ROUTER 3	ROUTER 4	ROUTER 5	ROUTER 6		
ROUTER 8	ROUTER 9	ROUTER 10	ROUTER 11	ROUTER 12	ROUTER 13	ROUTER 7	



SUPERSHOOTER 2: Tape Monitors